



Call Forwarding

1. Using the Phone's Menu:

- Press the "Menu" button on your phone.
- Navigate to the "Settings" or "Features" menu.
- Look for the "Call Forward" or "Forwarding" option.
- Select "Call Forward" and choose the type of forwarding you want (e.g., unconditional, busy, no answer).
- Enter the phone number to which you want calls forwarded.
- Save your settings.

2. Using Feature Codes:

- Some Grandstream phones allow you to set up call forwarding using feature codes. This typically involves dialling a specific code on your phone's keypad.

For example:

- *72: Activate unconditional call forwarding.
- *73: Deactivate unconditional call forwarding.
- *90: Activate call forwarding on busy.
- *91: Deactivate call forwarding on busy.
- *92: Activate call forwarding on no answer.
- *93: Deactivate call forwarding on no answer.
- Dial the appropriate code followed by the phone number to which you want calls forwarded. For example, to forward calls unconditionally to 555-1234, dial *72 followed by 5551234.

3. Using Mobile App (for Grandstream Wave):

- If you're using the Grandstream Wave softphone app on your smartphone, you can usually set up call forwarding within the app's settings menu. Look for options related to call handling or forwarding.